

MiniMax XT Single Gas CO Detector



2 year Disposable Unit

Calibration not needed !

**Why go through the Hassle and Expense
to calibrate your Gas detector Every Month?**

Simple operation, 2 year, no calibration single gas detector.

MiniMax XT was inspired by customer needs and technically crafted to be quite simply the easiest and most cost effective to use personal single gas unit on the market. Utilising patented Surecell™ and Reflex™ technology, the MiniMax XT provides 24/7 user confidence. That means solid, reliable and continuous protection... always.

Through our Customer Partner Programme, Honeywell Analytics identified that the market demanded more than tiny good looks. Our valued partners said that in addition to a small and rugged design, single gas monitors must offer comprehensive sensor options, simple operation and most importantly reliable, accurate readings – without false alarms triggered by common radio interference.

Simple one button operation reduces time consuming and costly training. Our unique Temperature Compensation and Cell Output Decay Compensation features ensure improved accuracy across wide temperature ranges, providing our 2 year, no calibration needed facility.

MiniMax XT is your out-of-the-box solution to simple, “XTra Sensory Detection.”

Manufactured by: HoneyWell Analytics

* Reflex™ not available for all sensors

* Oxygen detection products must only be used to detect Oxygen depletion in air

Features

Cost Effective

- No calibration required
- Unit may be calibrated if site procedures require
- Remaining lifetime display enables planned replacement
- 24 month continuous operation
- Low cost investment

Easy to Use

- Out-of-the-box solution
- One button operation
- Optional Interactive Training Guide available

Excellent EMC/RFI performance

- No false alarms due to walkie-talkies or mobile phones
- Exceeds with toughest industrial standards for RFI immunity and EMC compatibility

Reliable Operation

- Uses patented SureCell™ (CO and H2S only) and Reflex™* technology
- Stable and accurate gas readings
- Intrinsically safe Compact Design
- Small ergonomic design
- Comfortable to wear

Specifications:

CO Sensor Range:	0 to 1000 ppm
CO Display:	0 to 200ppm
Alarm Set Points:	Level 1: 35ppm; Level 2: 100ppm
Audible Alarm:	95db at 10cm (4 inches)
Visual Alarm:	High Intensity red LEDs
Vibrating Alarm:	Supplied as Standard
Shelf Life:	12 Months before activation
Max Operating Life:	2 Years after activation
Calibration:	Not Required
Dimensions:	3.4" (H) x 2" (W) x 1.1" (D)
Weight:	2.5 oz

Pricing:

MiniMax XT-CO: **\$150.00 Promotional Price while supply lasts**

Shipping: \$5 per unit; \$12 minimum

TMS Medical Technologies

33 Steeplechase Drive
Turnersville, NJ 08012

phone: (800)374-9798 or (856)374-4359
fax: (856)374-0419

email: sales@tmsmedtec.com
web: www.tmsmedtec.com