

Nomad 4000 Lumen Dual Action Portable Area Light & Spotlight



Attach diffuser lens for area lighting (120° beam).
Detach lens for focused spotlight (8° beam).



Weight	Length	Diameter	Max Height
17.0 lbs	33.0"	4.6"	95"
7.7 kg	840 mm	117 mm	2410 mm

Light Intensity and Battery Life

Intensity	Brightness	Battery Life
High	4,000 Lumen	2.5 Hours
Medium	2,700 Lumen	6 Hours
Low	1,300 Lumen	9 Hours

Portability

- Folds up to the size of a poster-tube for easy carry and storage
- Legs can be quickly deployed or put away
- Each leg extends to allow level placement on uneven terrain

◇ LED / LIGHT OUTPUT

- 1,300 – 4,000 Lumen
- 75 Watt Power Consumption
- Spotlight (8°) or Area Light with Diffuser Lens
- See up to 1.1 mi (2.0 km)

◇ FEATURES

- 3 Intensities (Low, Medium, High)
- Can be used as Spotlight or Area Light
- Telescoping and Rotating Head (340°)
- On / Mode Switch at Base of Unit
- Hold-down Clamp

◇ DURABILITY

- Nylon 66 Body with 6061-T6 Aluminum Head
- Fire Scene Ready
- All Weather

◇ BATTERY

- Rechargeable Lithium-Ion 200 WH
- Fully recharges in 8 Hours
- 500+ charge cycles
- Power Supply connects to AC or car battery
- Battery is replaceable by user

◇ WARRANTY

- Two (2) year warranty on all manufacturer defects from the date of original purchase

2 Years to Develop. 20 Seconds to Deploy

We took our time to save you yours.

The rechargeable LED Nomad quickly deploys without the need to remove it from its carry case. Plug it into AC or a DC cigarette lighter. Battery level indicator at the base of the unit lets you know how much battery life is left (green for fully charged, yellow for 2/3 charged and red for 1/3 charged). Battery charges in off mode.

Bazooka and Backpack Light

At 17 lbs and 33" long, the Nomad is light enough to transport anywhere. Shoulder strap permits hands-free transport. Throw it over your shoulder to help light your way.



Ideal for Rough Terrain

Leveling legs may independently adjusted and Bubble level indicator aids deployment. Anchor chain may be clipped to sand bag (or other objects) to combat wind. Lens cover keeps light head protected while in transit.



More Light with Less Hassles
No Generator, No Cords, No Noise

Pricing:

Nomad 4000 PN: FF-200-800

List: \$1,334.99 **(Promo: \$1,185.99)**

Shipping \$35



TMS Medical Technologies

33 Steeplechase Drive
Turnersville, NJ 08012

phone: (800)374-9798 or (856)374-4359
fax: (856)374-0419

email: sales@tmsmedtec.com
web: www.tmsmedtec.com